





ITEM NO.	PART NO.	NO. USED	DESCRIPTION	ITEM NO.	PART NO.	NO. USED	DESCRIPTION
1	125102-2	1	SPEED CHANGE LEVER ASSY	ACCESSORIES			
2	183968-6	1	HOUSING SET	A01	763178-7	1	½" KEYLESS DRILL CHUCK
4	266130-9	9	TAPPING SCREW BIND PT 3X16	A02	194227-3	1	18v NI-CAD BATTERY PA18 (1.3AH) (FOR OTHER 18V NI-CAD/NI-MH BATTERIES, SEE CATALOGUE)
5	232182-2	1	LEAF SPRING				
6	417283-9	1	F/R CHANGE LEVER	A03	DC1804	1	CHARGER DC1804
7	650566-6	1	SWITCH		DC1822	1	AUTOMOTIVE CHARGER DC1822
8	643924-3	1	BATTERY HOLDER	A04	----	1	BIT (SEE CATALOGUE FOR DETAILS)
9	251468-5	1	FLAT HEAD SCREW M6x22	A05	824744-6	1	PLASTIC CARRYING CASE (INCLUDES ITEM A06) (PHOTO N/A)
11	125275-1	1	GEAR ASSY	A06	417059-4	2	SNAP LOCK (L) (PHOTO N/A)
12	629834-8	1	DC MOTOR	A07	414938-7	1	BATTERY COVER
13	911108-4	2	P. H. SCREW M4X8				
14	655000-B	1	PLUG FOR CIGARETTE LIGHTER				