




PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
001		413P43-3	SLIDE LEVER U	1	PC.
002	2	141Y25-6	GRIP PIPE COMPLETE B	1	PC.
002	2	INC. 8068H3-4	CAUTION LABEL	1	PC.
002	2	INC. 8068H5-0	CAUTION LABEL	1	PC.
002	2	INC. 808723-2	CAUTION LABEL	1	PC.
002	2	INC. 819312-8	MAKITA LOGO LABEL	1	PC.
002	2	INC. 163525-6	LEAF SPRING COMPLETE	1	PC.
004		413P44-1	SLIDE LEVER L	1	PC.
005		266326-2	TAPPING SCREW 4X18	2	PC.
006		327723-8	SHAFT A	1	PC.
007		961003-8	RETAINING RING S-7	1	PC.
008		922241-7	HEX. SOCKET HEAD BOLT M5X25	1	PC.
009		922211-6	H.S.H.BOLT M5X12 WITH W	1	PC.
010		962112-6	RETAINING RING R-22	1	PC.
011		961006-2	RETAINING RING S-10	1	PC.
012		210167-8	BALL BEARING 6900LLB	1	PC.
013		227A69-7	SPIRAL BEVEL GEAR 11	1	PC.
014		961017-7	STOP RING E-3	1	PC.
015		327B80-6	STOPPER HOLDER	1	PC.
016		233201-7	COMPRESSION SPRING 6	1	PC.
017	1	327B81-4	* ROD 8	1	PC.
017	2	327E37-5	* ROD 8	1	PC.
018		265D20-7	H.S BUTTON HEAD BOLT M6X110	1	PC.
019	1	312E11-6	* JOINT	1	PC.
019	2	312H42-3	* JOINT	1	PC.
020		961006-2	RETAINING RING S-10	1	PC.
021		227A70-2	SPIRAL BEVEL GEAR 25	1	PC.
022		962106-1	RETAINING RING R-28	1	PC.
023		210163-6	BALL BEARING 6001DDW	1	PC.
024		327B79-1	SLEEVE 12	1	PC.
025		210163-6	BALL BEARING 6001DDW	1	PC.
026		227A71-0	SPIRAL BEVEL GEAR 15	1	PC.
027		213506-1	O RING 36	1	PC.
028		312E12-4	GEAR HOUSING	1	PC.
029		252190-7	HEX.LOCK NUT M6-10	1	PC.
030		922126-7	HEX. SOCKET HEAD BOLT M4X16	2	PC.
031		347B10-1	ANGULAR PLATE	1	PC.
032		265338-2	H.S.BOTTON HEAD BOLT M6X8	1	PC.

Item No	Type	Part No	Description	Qty	Unit
033		911128-8	P.H.SCREW M4X16 WITH WR	2	PC.
034		413P46-7	HANDLE	1	PC.
035		227A72-8	SPIRAL BEVEL GEAR 31	1	PC.
036		210163-6	BALL BEARING 6001DDW	1	PC.
037		213641-5	O RING 51	1	PC.
039		136987-1	CRANK HOUSING ASS'Y	1	PC.
039	INC.	263002-9	RUBBER PIN 4	1	PC.
040		922126-7	HEX. SOCKET HEAD BOLT M4X16	4	PC.
041		327B78-3	SPINDLE	1	PC.
042		347B34-7	FRICTION PLATE U	1	PC.
043		313471-5	CRANK	1	PC.
044		210062-2	BALL BEARING 607ZZ	1	PC.
045		413P97-0	DUST GUARD	1	PC.
046		313470-7	SPACER	2	PC.
047		347B33-9	LOWER PLATE	1	PC.
048		422A85-6	SPONGE SEAL	1	PC.
049		422A16-5	DUST GUARD	1	PC.
050		922241-7	HEX. SOCKET HEAD BOLT M5X25	2	PC.
051		347B35-5	FRICTION PLATE L	1	PC.
052		413P45-9	UNDER COVER	1	PC.
054		265D11-8	H.S.H.BOLT M4X18 WITH W	4	PC.
055		264013-7	HEX. LOCK NUT M5-8	5	PC.
058		327B33-5	GUIDE BAR 500	1	PC.
059		347B09-6	PLATE 500	1	PC.
060		725318-5	SHEAR BLADE 500 - N/A individually	1	PC.
061		725318-5	SHEAR BLADE 500 - N/A individually	1	PC.
064		265D00-3	+TRUSS HEAD SCREW M5X22	5	PC.
065		1912G3-7	SHEAR BLADE 500 SET	1	PC.
065	INC.	199450-5	GREASE VESSEL SET	1	PC.
065	INC.		Item No. 55,58-61,64		
065	INC.	257A00-9	COLLARED SLEEVE 5 (for Item No. 64)	1	PC.
A01	2	4133Y0-8	BLADE COVER 500	1	PC.
A02		422A15-7	CAP 24	1	PC.
A03		424434-7	CAP 24	2	PC.
A04		783202-0	HEX. WRENCH 4	1	PC.
C01		8200U7-5	Carton for EN402MP	1	PC.

SERVICE CHANGES: EN402MP

1. Changes on Joint and Rod 8 (T/I#DV191)

Item No.	Description	Type 1	Type 2
19	JOINT	312E11-6	312H42-3
17	ROD 8	327B81-4	327E37-5

Above parts are completely interchangeable as a set.

Detailed information

