



Item No.	Type	Sub	Part No.	Description	Qty	Unit
001			GM00002458	LENS	1	PC.
002			GM00002459	USB SWITCH BUTTON	1	PC.
003			GM00002460	STRAP HOOK	1	PC.
004			GM00002461	USB COVER	1	PC.
005			GM00002471	LED PCBA ASSY	1	PC.
006			GM00002472	USB PCBA ASSY	1	PC.
007			GM00002473	MAIN PCBA ASSY	1	PC.
008			GM00002499	BODY ASSY BLUE	1	PC.
009			GM00002468	SWITCH SPRING	1	PC.
010			GM00002469	SWITCH SPRING BRACKET	1	PC.
011			GM00002470	SWITCH ASSY	1	PC.
012			GM00001012	SCREW 3X12 PB BLACK ZN	3	PC.

ACCESSORIES

- Visit www.makita.ca for more accessories information -

A01			GM00002457	LAMP SHADE	1	PC.
A02			-----	18V LI-ION BATTERY		
A03			-----	BATTERY CHARGER		