



## PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
001		326798-4	SHAFT A	1	PC.
002		1413A5-7	SHAFT PIPE COMPLETE B	1	PC.
002	INC.	8068H3-4	CAUTION LABEL	1	PC.
002	INC.	8096E7-2	CAUTION LABEL	1	PC.
003		253047-5	FLAT WASHER 6	1	PC.
004		265E61-9	HEX.BOLT M5X32	1	PC.
005		271477-8	LEVER 53	1	PC.
006		234347-2	COMPRESSION SPRING 11	1	PC.
007		347577-7	WASHER 6	1	PC.
008		265135-6	COUNTERSUNK HEAD SCREW M4X10	1	PC.
009		961006-2	RETAINING RING (EXT) S-10	2	PC.
010		4133U0-0	WHEEL HOLDER 300	1	PC.
011		413D96-0	WHEEL 130	2	PC.
012		253828-7	FLAT WASHER 10	2	PC.
013		4133U1-8	CAP	2	PC.
014		961003-8	RETAINING RING (EXT) S-7	1	PC.
015		962102-9	RETAINING RING (INT) R-22	1	PC.
016		961036-3	RETAINING RING (EXT) WR-10	1	PC.
017		210167-8	BALL BEARING 6900LLB	1	PC.
018		227A88-3	SPIRAL BEVEL GEAR 11	1	PC.
019		922241-7	HEX. SOCKET HEAD BOLT M5X25 W	1	PC.
020		141S15-3	GEAR HOUSING COMPLETE	1	PC.
021		922211-6	HEX. SOCKET HEAD BOLT M5X12 W	1	PC.
022		211493-8	BALL BEARING 609DDW	1	PC.
023		227A89-1	SPIRAL BEVEL GEAR 52	1	PC.
024		327C06-4	SPINDLE	1	PC.
025		211247-3	BALL BEARING 6002DDW	1	PC.
026		422A36-9	GASKET	1	PC.
027		141S16-1	GEAR HOUSING COVER COMPLETE	1	PC.
028		922126-7	HEX. SOCKET HEAD BOLT M4X16 W	4	PC.
029		422A37-7	DUST GUARD	1	PC.
030		347B34-7	FRICTION PLATE U	1	PC.
031		327C07-2	CRANK	1	PC.
032		1916X3-0	SHEAR BLADE 500 SET	1	PC.
032	INC.	252331-5	HEX. LOCK NUT M5-8	7	PC.
032	INC.	199450-5	GREASE VESSEL SET	1	PC.
032	INC.	265E60-1	+TRUSS HEAD SCREW M5X16	7	PC.
032	INC.	257A04-1	SLEEVE 5	7	PC.

Item No	Type	Part No	Description	Qty	Unit
032	INC.	257A05-9	RING 8	7	PC.
033		347B49-4	UNDER PLATE	1	PC.
034		265D17-6	HEX. SOCKET HEAD BOLT M5X25	4	PC.
A01		4133V1-5	BLADE COVER 500	1	PC.
A02		422A15-7	CAP 24	1	PC.
A03		424434-7	CAP 24	2	PC.
A04		783202-0	HEX. WRENCH 4	1	PC.
C01B		8228K7-9	CARTON(3L)	1	PC.
F01		1912V6-6	SHEAR BLADE 330 SET	1	PC.