




01 - 2010
1806B
6-3/4" PLANER



PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
001		664276-9	CORD W/PLUG 2P-16-5.0M, SJ	1	PC.
003		682505-8	CORD GUARD 10-90	1	PC.
004		911158-9	PAN HEAD SCREW M4X30	2	PC.
005		911300-2	PAN HEAD SCREW M5X75	2	PC.
006		911213-7	PAN HEAD SCREW M5X12	4	PC.
007		181151-9	HANDLE SET	1	SET
008		911253-5	PAN HEAD SCREW M5X30	2	PC.
009	2	156414-2	MOTOR HOUSING	1	PC.
009	2	INC. 643653-8	BRUSH HOLDER 6.5-13.5	2	PC.
010		911133-5	PAN HEAD SCREW M4X18	2	PC.
011		687031-2	STRAIN RELIEF	1	PC.
012		911103-4	PAN HEAD SCREW M4X6	2	PC.
013		651018-0	SWITCH (TRIGGER)	1	PC.
014		911228-4	PAN HEAD SCREW M5X18	3	PC.
015		281007-7	HOLDER	1	PC.
016		911324-8	PAN HEAD SCREW M6X16	1	PC.
017		854895-1	NAME PLATE F/ 1806B	1	PC.
018		953106-2	RIVET 0-5	4	PC.
019		271249-1	KNOB 64 (OLD# 271202-7 - N/L/A)	1	PC.
020		253004-3	FLAT WASHER 13	1	PC.
021		911158-9	PAN HEAD SCREW M4X30	2	PC.
022	1	316966-7	CHIP COVER	1	PC.
022	2	312E29-7	CHIP COVER	1	PC.
023		911206-4	PAN HEAD SCREW M5X10	2	PC.
024	1	285004-5	BEARING COVER 38	1	PC.
025		911206-4	PAN HEAD SCREW M5X10	2	PC.
026	2	142892-2	* MAIN FRAME	1	PC.
026	2	INC. 817733-8	CAUTION LABEL	1	PC.
026	2	INC. 804W95-1	* SCALE LABEL	1	PC.
027		423094-2	RUBBER PACKING	1	PC.
028		231233-8	COMPRESSION SPRING 24	1	PC.
029	1	315575-9	FRONT BASE	1	PC.
029	2	316917-0	FRONT BASE	1	PC.
030		265484-1	HEX. SOCKET HEAD BOLT M6X17	10	PC.
031	3	187675-3	DRUM PLATE (2PCS/SET)	1	SET
032		341376-9	WASHER 10	1	PC.
034		211067-5	BALL BEARING 6200ZZ	1	PC.
035		911256-9	PAN HEAD SCREW M5X35	2	PC.


Item No	Type	Part No	Description	Qty	Unit
036		643650-4	BRUSH HOLDER CAP 6.5-13.5	2	PC.
037	2	194986-9	CARBON BRUSH CB-154 2PC/SET W/ ORIGIN	1	SET
037	3	181047-4	CARBON BRUSH CB-154 2PCS/SET W/ ORIGIN	1	SET
037	Opt.2	194987-7	A.C. CARBON BRUSH CB-155 2PC/SET (W/ ORIGIN)	1	SET
038		251212-0	+ FLAT HEAD SCREW M5X13	4	PC.
039		161132-9	DRUM	1	PC.
040		341377-7	WASHER 12	1	PC.
041		211107-9	BALL BEARING 6201ZZ	1	PC.
042		523022-8	FIELD ASS'Y 115V-130V (OLD# 623022-9)	1	PC.
042	INC.	654502-4	CONNECTOR P-2	2	PC.
042	INC.	654020-2	RING TERMINAL	2	PC.
044	2	211061-7	BALL BEARING 6000LLB	1	PC.
045		681635-2	INSULATION WASHER	1	PC.
046		513386-8	ARMATURE ASS'Y 115V (OLD# 613311-0)	1	PC.
046	INC.		Item No. 44,45,47,52,53		
047		241013-4	FAN 80	1	PC.
048		222007-8	V-PULLEY 6-23L	1	PC.
049		911263-2	PAN HEAD SCREW M5X40	5	PC.
050		152214-8	BRACKET COMPLETE (OLD# 411407-9)	1	PC.
050	INC.		Item No. 55		
051		341384-0	WASHER 26	1	PC.
052		211106-1	BALL BEARING 6201LLB	1	PC.
053		213102-5	DUST SEAL 12	1	PC.
054		263005-3	RUBBER PIN 6	1	PC.
055		263005-3	RUBBER PIN 6	1	PC.
056	2	159942-6	DRUM HOUSING	1	PC.
056	2	INC.	Item No. 54		
057		911121-2	PAN HEAD SCREW M4X14	4	PC.
058		222006-0	V-PULLEY 6-30	1	PC.
059		225042-5	POLY V-BELT 6-304	1	PC.
060	1	343301-6	BELT COVER	1	PC.
060	2	347B54-1	BELT COVER	1	PC.
061		911206-4	PAN HEAD SCREW M5X10	1	PC.
063		421490-8	RUBBER RING 26	1	PC.
100		654038-3	INSULATED TERMINAL FT1.25-M4	4	PC.
101		652014-1	P.H. SCREW M4 X 8	4	PC.
102		652252-5	CLAMP WASHER	4	PC.
400		762001-3	TRIANGULAR RULE	1	PC.
401		934201-7	WING NUT M5	2	PC.

Item No	Type	Part No	Description	Qty	Unit
402		123053-3	GUIDE RULE ASS'Y	1	PC.
402	INC.		Item No. 401,403		
403		923211-9	CAP SQUARE NECK BOLT M5X12	2	PC.
404	1	793186-4	6-3/4" PLANER BLADE HSS	1	SET
404	2	D-63666	6-3/4" PLANER BLADE HSS 2PC/SET	1	SET
405		783202-0	HEX. WRENCH 4	1	PC.
408		123006-2	SHARPENING HOLDER ASS'Y	1	PC.
408	INC.	341009-6	PRESSURE PLATE - (N/A as individually)	1	PC.
408	INC.	312846-5	SHARPENING HOLDER - (N/A as individually)	1	PC.
408	INC.	251920-3	C.S.N. BOLT M6X30	2	PC.
408	INC.	934301-3	WING NUT M6	2	PC.
410		794060-9	DRESSING STONE 180MM	1	PC.
411		181575-9	JOINT 70	1	PC.
412		122397-8	NOZZLE ASSY	1	PC.
412	INC.	213701-3	O RING	1	PC.
E01		231668-3	* TORSION SPRING 15 (Added)	1	PC.
E02		346815-4	* PLATE (Added)	1	PC.
E03		418155-1	* FOOT (Added)	1	PC.
E04		911211-1	* PAN HEAD SCREW M5X12 (Added)	2	PC.

SERVICE CHANGES: 1806B


1. Changes on Motor Housing

Type 1



Set screws M5X8 are used as the stopper of Brush Holder

Type 2



Screws are eliminated


2. Changes on Main frame

(TI#A3962)

Item No	Description	Type 1	Type 2
26	Main Frame	159984-0	142892-2
26 INC.	Scale Plate > Scale Label	816688-4	804W95-1
26 INC.	Rivet 0-5	953106-2	-----
E01	Torsion Spring 15	-----	231668-3
E02	Plate	-----	346815-4
E03	Foot	-----	418155-1
E04	Pan Head Screw M5x12	-----	911211-1

Above parts are completely interchangeable as a set.

Type 1



Type 2

