





Item No.	Part No.	No. Used	Description
1	183682-4	1	Housing Set (Includes Items 7, 43 & 44)
2	655000-B	1	Plug for Cigarette Lighter
3	266130-9	8	Tapping Screw Bind PT 3X16
4	416079-5	1	Change Lever F/R
6	638288-8	1	Switch Unit
7	263024-9	1	Rubber Pin 4
10	687085-9	1	Holder
11	654168-0	1	Spring Terminal (+)
12	654169-8	1	Spring Terminal (-)
17	151947-2	1	Hammer Case Com.
18	265999-8	4	Tapping Screw 4X25
19	261108-7	1	Nylon Washer 14
20	231964-9	1	Ring Spring 7
21	323993-7	1	Anvil
22	324404-5	1	Hammer
23	216001-0	24	Steel Ball 3.5
24	267175-0	1	Flat Washer 24
25	233276-6	1	Compression Spring 25
26	267766-7	1	Cup Washer 14
27	324220-5	1	Spindle
28	226336-1	2	Spur Gear 22
29	256253-1	2	Pin 5
30	267212-0	1	Flat Washer 12
31	227001-5	1	Internal Gear 51
32	216011-7	2	Steel Ball 5.6
33	211140-1	1	Ball Bearing 6901LLB
34	417269-3	1	Internal Gear Case
35	632965-4	1	Yoke Unit
36	619132-8	1	Armature
37	638156-5	1	Endbell Com.
38	193466-2	2	Carbon Brush CB-434 (2pcs/Set)
39	643933-2	2	Brush Holder Cap
40	689096-0	1	FET Spacer
41	266170-7	1	Tapping Screw ST3X8
43	819063-3	1	Makita Label
44	263024-9	1	Rubber Pin 4

Item No.	Part No.	No. Used	Description
Accessories			
A01	414938-7	1	Battery Cover
A02	193158-3	1	14.4V Ni-MH Battery 1434 (2.6Ah)
	192699-A	1	14.4V Ni-MH Battery 1433 (2.2Ah)
	192600-1	1	14.4V Ni-Cad Battery 1422 (2.0Ah)
	193139-7	1	14.4V Ni-MH Battery 1435 (3.0Ah)
A03	DC1411	1	DC1411 Fast Charger For 7.2V ~ 14.4V Ni-Cad & Ni-MH Batteries (1.3Ah ~ 3.0Ah)
	DC1413	1	DC1413 Fast Charger For 7.2V ~ 14.4V Ni-Cad & Ni-MH Batteries (1.3Ah ~ 3.0Ah)
	DC1414	1	DC1414 Fast Charger For 7.2V ~ 14.4V Ni-Cad & Ni-MH Batteries (1.3Ah ~ 3.0Ah)
	DC1439	1	Rapid Charger For 7.2V ~ 14.4V Ni-Cad & Ni-MH Battery (1.3Ah ~ 3.0Ah)
	DC1803	1	DC1803 Charger For Ni-Cad & Ni-MH 7.2V ~ 18V Batteries (1.3Ah ~ 3.0Ah)
	DC1804	1	DC1804 Charger For Ni-Cad & Ni-MH 7.2V ~ 18V Batteries (1.3Ah ~ 3.0Ah)
	DC1422	1	DC1422 Automotive Charger For 7.2V ~ 14.4V Ni-Cad & Ni-MH Batteries (1.3Ah ~ 3.0Ah)
	DC1822	1	DC1822 Automotive Charger For 7.2V ~ 18V Ni-Cad & Ni-MH Batteries (1.3Ah ~ 3.0Ah) (Includes Item 2)
A04	824635-1	1	Plastic Carrying Case (Includes Item A05)
A05	186347-7	2	Slide Latch Set (2pcs/Set)

REPAIR TOOLS

1R045 - Gear Extractor (Large)

181573-3 - Makita Grease N No.2 (Bit Grease)