



## PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
001		265995-6	TAPPING SCREW 4X18	12	PC.
002		1831P4-6	HOUSING SET	1	SET
002	INC.	263005-3	RUBBER PIN 6	2	PC.
002	INC.	263032-0	RUBBER PIN 4	2	PC.
003		650060-8	SWITCH C3JR-5BM-PAND-2	1	PC.
004		232848-4	COMPRESSION SPRING 4	1	PC.
005		413X17-2	TRIGGER	1	PC.
006		632V61-0	SWITCH UNIT	1	PC.
007		232964-2	LEAF SPRING	1	PC.
008		632P65-6	TERMINAL UNIT	1	PC.
009		266007-8	TAPPING SCREW BIND PT 3X10	2	PC.
010		620S71-1	SWITCH CIRCUIT COMPLETE	1	PC.
012		265E40-7	HEX.SOCKET HEAD SHOULDER BOLT	1	PC.
013		620R94-3	CONTROLLER	1	PC.
014		652119-7	PAN HEAD SCREW M2X6	6	PC.
015		266130-9	TAPPING SCREW BIND PT 3X16	5	PC.
016		629D03-5	STATOR	1	PC.
017		1831P9-6	MOTOR HOUSING SET	1	SET
018		685722-9	SPONGE	1	PC.
020		210169-4	BALL BEARING 607LLB	1	PC.
021	1	519892-1	ROTOR ASSEMBLY	1	PC.
021	1	INC.	Item No. 20,22		
022		210223-4	BALL BEARING 608ZZ	1	PC.
023		122H96-0	GEAR ASSEMBLY	1	PC.
024		265853-6	HEX. SOCKET HEAD BOLT M5X18	2	PC.
025		422B18-7	GEAR CUSHION	4	PC.
026		227B54-6	SPUR GEAR 13	5	PC.
027		227B41-5	INTERNAL GEAR 44	1	PC.
028		141U61-8	CARRIER COMPLETE	1	PC.
029		211423-9	BALL BEARING 6806DDW	1	PC.
030		922342-1	HEX. SOCKET HEAD BOLT M6X25	4	PC.
031		327D23-0	VALVE CAP	1	PC.
032		213007-9	O RING 8	1	PC.
033		243138-0	VALVE CORE	1	PC.
034		312E84-9	TOP CAP	1	PC.
035		413X16-4	SLIDE RING	2	PC.
036	2	213B05-5	X-RING 40	1	PC.
037		141U59-5	DRIVER COMPLETE	1	PC.

Item No	Type	Part No	Description	Qty	Unit
038		327D22-2	CYLINDER	1	PC.
039		213663-5	O RING 55	2	PC.
040		422B15-3	SEAL RING	1	PC.
041		141U65-0	CHAMBER COMPLETE	1	PC.
042		422B14-5	FRONT CUSHION	1	PC.
043		312E81-5	NOSE	1	PC.
044		251490-2	H.S.H.BOLT M5X14 WITH WR	3	PC.
045		422B16-1	SIDE CUSHION	1	PC.
046		265173-8	PAN HEAD SCREW M3X8	2	PC.
047		620S90-7	SENSOR CIRCUIT	1	PC.
048		422B16-1	SIDE CUSHION	1	PC.
050		620R02-4	LED CIRCUIT	1	PC.
051		137163-0	SWITCH ASSEMBLY	1	PC.
052		232843-4	LEAF SPRING	1	PC.
053		961053-3	RETAINING RING (EXT) S-13	1	PC.
054		253595-4	FLAT WASHER 14	1	PC.
055		141U60-0	HOLDER COMPLETE	1	PC.
056		347C07-6	PIN COVER	1	PC.
057		256A54-3	PIN 5	8	PC.
058		327F05-4	LIFTER	1	PC.
059		256A01-4	PIN 3.5	1	PC.
060		232846-8	COMPRESSION SPRING 4	1	PC.
061		327D05-2	LIFTER SHAFT	1	PC.
062		211236-8	BALL BEARING 6002DDW	1	PC.
063		312E82-3	LIFTER CAP	1	PC.
064		265D66-3	HEX. SOCKET HEAD BOLT M5X20 WG	2	PC.
065		232847-6	COMPRESSION SPRING 12	1	PC.
066		264027-6	HEX LOCK NUT M6-10	1	PC.
067		327D17-5	ADJUSTER SLEEVE	1	PC.
068		347C06-8	CONTACT ARM	1	PC.
069		216001-0	STEEL BALL 3.5	1	PC.
070		232417-1	COMPRESSION SPRING 3	1	PC.
071		413X07-5	ADJUSTER DIAL	1	PC.
072		327D20-6	ADJUSTER SHAFT	1	PC.
073		313673-3	CONTACT TOP	1	PC.
074	2	213005-3	O RING 5	2	PC.
075		313503-8	DRIVER GUIDE	1	PC.
076		265D55-8	HEX. SOCKET HEAD BOLT M5X12	2	PC.
077		265915-0	HEX. SOCKET HEAD BOLT M6X10	1	PC.

Item No	Type	Part No	Description	Qty	Unit
078		267214-6	FLAT WASHER 6	1	PC.
079		313504-6	UNDER DRIVER GUIDE	1	PC.
080		422B13-7	PUSHER CUSHION	1	PC.
081		413X12-2	MAGAZINE CAP	1	PC.
082		922212-4	HEX. SOCKET HEAD BOLT M5X12	1	PC.
083		1411Y6-1	MAGAZINE COMPLETE	1	PC.
083	INC.	8088G5-9	CAUTION LABEL	1	PC.
084		347C08-4	NAIL RAIL	1	PC.
085		141U43-0	SPIRAL SPRING COMPLETE	1	PC.
086		256428-2	PIN 5-8	1	PC.
087		262054-7	URETHANE RING 3	1	PC.
088		347C10-7	PUSHER	1	PC.
089		234084-8	COMPRESSION SPRING 3	1	PC.
090		413X13-0	PUSHER LEVER	1	PC.
091		256A57-7	PIN 4	1	PC.
092		347C09-2	LOCK PLATE	1	PC.
093		233339-8	COMPRESSION SPRING 3	1	PC.
094		262054-7	URETHANE RING 3	1	PC.
095		256A57-7	PIN 4	1	PC.
096		122J47-5	MAGAZINE ASSEMBLY	1	PC.
096	INC.		Item No. 77-95		
097		8152L8-5	BN001G NAME PLATE	1	PC.
098		8152M0-8	BN001G SERIAL NO. LABEL	1	PC.
A01		141X57-7	HOOK ASSEMBLY C-SHAPE	1	PC.
A02		265D55-8	HEX. SOCKET HEAD BOLT M5X12	3	PC.
A03		347C14-9	HOOK	1	PC.
A04		4133Y2-4	NOSE ADAPTER	1	PC.
A05		783202-0	HEX. WRENCH 4	1	PC.
A06		-----	40V MAX LI-ION BATTERY		
A07		-----	BATTERY CHARGER		
F02		1916P4-2	NOSE ADAPTER SET	1	PC.