



PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
001		266130-9	TAPPING SCREW BIND PT 3X16	11	PC.
002		1831D7-6	HOUSING SET	1	SET
002	INC.	263005-3	RUBBER PIN 6	2	PC.
002	INC.	252126-6	HEX. LOCK NUT M4-7	2	PC.
002	INC.	252103-8	HEX. LOCK NUT M5-8	1	PC.
003		911248-8	PAN HEAD SCREW M5X28	1	PC.
004		650060-8	SWITCH C3JR-5BM-PAND-2	1	PC.
005		232884-0	COMPRESSION SPRING 7	1	PC.
006	2	1413L6-2	TRIGGER COMPLETE	1	PC.
007		632V61-0	SWITCH UNIT	1	PC.
008		232889-0	LEAF SPRING	1	PC.
009		654908-6	TERMINAL	1	PC.
010		232876-9	COMPRESSION SPRING 7	2	PC.
011		620P12-9	CONTROLLER	1	PC.
012		652069-6	FLAT HEAD SCREW M3X6	3	PC.
013		266490-9	TAPPING SCREW PT 2X6	3	PC.
014		4130V8-3	LED HOLDER	1	PC.
015		620P87-8	LED CIRCUIT	1	PC.
016		629A28-1	STATOR	1	PC.
017		210231-5	BALL BEARING 625ZZ	1	PC.
018		519865-4	ROTOR ASSY	1	PC.
018	INC.		Item No. 17,19		
019		210005-4	BALL BEARING 608DDW	1	PC.
020		266007-8	TAPPING SCREW BIND PT 3X10	2	PC.
021		620P99-1	SWITCH CIRCUIT COMPLETE	1	PC.
023		122G77-8	GEAR ASSEMBLY	1	PC.
024		227B71-6	SPUR GEAR 14	4	PC.
025		141Y39-5	CARRIER COMPLETE	1	PC.
026		210168-6	BALL BEARING 6805DDW	1	PC.
027	2	265E16-4	TAPPING SCREW 4X18	2	PC.
028		141Y44-2	INNER HOUSING COMPLETE	1	PC.
029		911007-0	PAN HEAD SCREW M3X8	1	PC.
030		620P94-1	SENSOR CIRCUIT	1	PC.
031	2	265E16-4	TAPPING SCREW 4X18	4	PC.
032		961006-2	RETAINING RING S-10	1	PC.
033		347C87-2	FLAT WASHER 10	1	PC.
034		162D44-3	HOLDER COMPLETE	1	PC.
035		232885-8	COMPRESSION SPRING 4	1	PC.

Item No	Type	Part No	Description	Qty	Unit
036		347C81-4	LIFTER PLATE	1	PC.
037		256173-9	PIN 3.5	6	PC.
038		327E03-2	LIFTER	1	PC.
039		327E09-0	LIFTER SHAFT	1	PC.
040		211391-6	BALL BEARING 6900LLU	1	PC.
041		4130V1-7	LIFTER CAP	1	PC.
042		8148K6-5	DBN501 SERIAL NO. LABEL	1	PC.
043		8148K4-9	DBN501 NAME PLATE	1	PC.
044		922232-8	HEX. SOCKET HEAD BOLT M5X20	4	PC.
045		327D23-0	VALVE CAP	1	PC.
046		213007-9	O RING 8	1	PC.
047		243138-0	VALVE CORE	1	PC.
048		312H24-5	TOP CAP	1	PC.
049		213A78-2	X RING 23	1	PC.
050		4130T8-9	SLIDE RING	2	PC.
051		137238-5	DRIVER ASSEMBLY	1	PC.
052		259092-8	SPIRAL RETAINING RING (EXT)36	1	PC.
053		422B82-8	SEAL RING	1	PC.
054		141Y40-0	CHAMBER COMPLETE	1	PC.
055	2	213A95-2	O RING 33	2	PC.
056		327D99-7	CYLINDER	1	PC.
057		422B80-2	FRONT CUSHION	1	PC.
058		266007-8	TAPPING SCREW BIND PT 3X10	3	PC.
059		4130U1-0	ADJUSTER COVER	1	PC.
060		141V44-4	SWITCH PLATE COMPLETE	1	PC.
061		232883-2	LEAF SPRING	1	PC.
062		232882-4	COMPRESSION SPRING 9	1	PC.
063		141Y46-8	ADJUSTER COMPLETE	1	PC.
064		213021-5	O RING 5	1	PC.
065		961017-7	STOP RING E-3	1	PC.
066		347C76-7	CONTACT ARM	1	PC.
067		422B81-0	NOSE ADAPTER	1	PC.
068		951066-2	SPRING PIN 3-18	2	PC.
069		313569-8	DRIVER GUIDE	1	PC.
070		4130T7-1	LATCH COVER	1	PC.
071		162D43-5	LATCH	1	PC.
072		313568-0	UNDER DRIVER GUIDE	1	PC.
073		265911-8	HEX. SOCKET HEAD BOLT M4X8	2	PC.
074		922228-9	H.S.H.BOLT M5X18 WITH WR	2	PC.

Item No	Type	Part No	Description	Qty	Unit
075		922117-8	HEX. SOCKET HEAD BOLT M4X12	1	PC.
076		347E02-8	NAIL PLATE	1	PC.
077		1410P1-2	MAGAZINE COMPLETE	1	PC.
077	INC.	8081T5-8	CAUTION LABEL	1	PC.
078		313591-5	STOPPER	1	PC.
079		233018-8	COMPRESSION SPRING 3	1	PC.
080		347C74-1	PUSHER	1	PC.
081		459313-0	SLEEVE	2	PC.
082		256877-3	PIN 3	1	PC.
083		413329-9	LEVER	1	PC.
084		233117-6	COMPRESSION SPRING 6	1	PC.
085		232881-6	COMPRESSION SPRING 6	2	PC.
086		262054-7	URETHANE RING 3	1	PC.
087		141Y41-8	SLIDE DOOR COMPLETE	1	PC.
087	INC.	8081T4-0	CAUTION LABEL	1	PC.
A01		251314-2	+ SCREW M4X12	1	PC.
A02		346449-3	HOOK	1	PC.
A03		422B81-0	NOSE ADAPTER	2	PC.
A04		-----	18V LI-ION BATTERY		
A05		-----	BATTERY CHARGER		
C01B		8206X4-8	CARTON F/DBN501Z	1	PC.