



PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
001		265995-6	TAPPING SCREW 4X18	12	PC.
002	4	1831P2-0	* HOUSING SET	1	SET
002	4	INC. 263032-0	* RUBBER PIN 4	2	PC.
003		650060-8	SWITCH C3JR-5BM-PAND-2	1	PC.
004		232848-4	COMPRESSION SPRING 4	1	PC.
005		413X17-2	TRIGGER	1	PC.
006		632V61-0	SWITCH UNIT	1	PC.
007	1	232842-6	* LEAF SPRING	1	PC.
007	2	232964-2	* LEAF SPRING	1	PC.
008		422B50-1	HOLDER CUSHION	4	PC.
009		266130-9	TAPPING SCREW BIND PT 3X16	2	PC.
010		1830M8-1	BATTERY HOLDER SET	1	SET
010		INC. 263005-3	RUBBER PIN 6	2	PC.
012		654908-6	TERMINAL	1	PC.
013		232876-9	COMPRESSION SPRING 7	2	PC.
014		422B17-9	BATTERY CUSHION	2	PC.
015		266007-8	TAPPING SCREW BIND PT 3X10	2	PC.
016	1	620P22-6	SWITCH CIRCUIT COMPLETE	1	PC.
018		265D66-3	H.S.H.BOLT M5X20 WITH WG	1	PC.
019	1	629C77-0	* STATOR COMPLETE	1	PC.
019	2	629D43-3	* STATOR COMPLETE	1	PC.
020		266130-9	TAPPING SCREW BIND PT 3X16	5	PC.
021		1830P6-6	MOTOR HOUSING SET	1	SET
023		210169-4	BALL BEARING 607LLB	1	PC.
024		519862-0	ROTOR ASS'Y	1	PC.
024		INC.	Item No. 23,25		
025		210223-4	BALL BEARING 608ZZ	1	PC.
026	2	265853-6	H.S.H.BOLT M5X18	2	PC.
027		122G07-9	GEAR ASSEMBLY	1	PC.
028		227B41-5	INTERNAL GEAR 44	1	PC.
029		227B54-6	SPUR GEAR 13	5	PC.
030		141U61-8	CARRIER COMPLETE	1	PC.
031		211423-9	BALL BEARING 6806DDW	1	PC.
032		422B18-7	GEAR CHSHION	4	PC.
033		685722-9	SPONGE	1	PC.
034		922342-1	HEX. SOCKET HEAD BOLT M6X25	4	PC.
035		327D23-0	VALVE CAP	1	PC.
036		213007-9	O RING 8	1	PC.

Item No	Type	Part No	Description	Qty	Unit
037		243138-0	VALVE CORE	1	PC.
038		312E84-9	TOP CAP	1	PC.
039		413X16-4	SLIDE RING	2	PC.
040	2	213B05-5	X-RING 40	1	PC.
041		141U66-8	DRIVER COMPLETE	1	PC.
042		327D22-2	CYLINDER	1	PC.
043		213663-5	O RING 55	2	PC.
044		422B15-3	SEAL RING	1	PC.
045		141U65-0	CHAMBER COMPLETE	1	PC.
046		422B14-5	FRONT CUSHION	1	PC.
047		312E81-5	NOSE	1	PC.
048	2	251490-2	H.S.H BOLT M5X14 WITH WR	3	PC.
049		422B16-1	SIDE CUSHION	1	PC.
050		265173-8	PAN HEAD SCREW M3X8	2	PC.
051	1	620N67-2	* SENSOR CIRCUIT	1	PC.
051	2	620S90-7	* SENSOR CIRCUIT	1	PC.
052		961053-3	RETAINING RING (EXT) S-13	1	PC.
053		422B16-1	SIDE CUSHION	1	PC.
054		620R02-4	LED CIRCUIT	1	PC.
055		137163-0	SWITCH ASSEMBLY	1	PC.
057		232843-4	LEAF SPRING	1	PC.
058		253595-4	FLAT WASHER 14	1	PC.
059		141U60-0	HOLDER COMPLETE	1	PC.
060		347C07-6	PIN COVER	1	PC.
061		232846-8	COMPRESSION SPRING 4	1	PC.
062		256A54-3	PIN 5	9	PC.
063		327D06-0	LIFTER	1	PC.
064		327D05-2	LIFTER SHAFT	1	PC.
065		211236-8	BALL BEARING 6002DDW	1	PC.
066		312E82-3	LIFTER CAP	1	PC.
067	2	265D66-3	H.S.H.BOLT M5X20 WITH WR	2	PC.
068		232847-6	COMPRESSION SPRING 12	1	PC.
069		264027-6	HEX LOCK NUT M6-10	1	PC.
070		327D17-5	ADJUSTER SLEEVE	1	PC.
071		347C06-8	CONTACT ARM	1	PC.
072		216001-0	STEEL BALL 3.5	1	PC.
073		232417-1	COMPRESSION SPRING 3	1	PC.
074		413X07-5	ADJUSTER DIAL	1	PC.
075	1	313502-0	* CONTACT TOP	1	PC.

Item No	Type	Part No	Description	Qty	Unit
076		213005-3	O RING 5	2	PC.
077		327D20-6	ADJUSTER SHAFT	1	PC.
078		313505-4	DRIVER GUIDE	1	PC.
079		265D55-8	H.S.H BOLT M5X12	2	PC.
080		122H37-6	MAGAZINE ASS'Y	1	PC.
080	INC.		Item No. 81-99		
081		313506-2	UNDER DRIVER GUIDE	1	PC.
082		413X22-9	MAGAZINE CAP	1	PC.
083		922212-4	HEX. SOCKET HEAD BOLT M5X12	1	PC.
084		141V06-2	MAGAZINE PLATE	1	PC.
084	INC.	8076Y2-6	CAUTION LABEL	1	PC.
085		347C11-5	NAIL RAIL	1	PC.
086		141U43-0	SPIRAL SPRING COMPLETE	1	PC.
087		256428-2	PIN 5-8	1	PC.
088		262054-7	URETHANE RING 3	1	PC.
089		347C13-1	PUSHER	1	PC.
090		234084-8	COMPRESSION SPRING 3	1	PC.
091		413X23-7	PUSHER LEVER	1	PC.
092		256A57-7	PIN 4	1	PC.
093		347C12-3	LOCK PLATE	1	PC.
094	1	232354-9	COMPRESSION SPRING 3	1	PC.
094	2	233339-8	COMPRESSION SPRING 3	1	PC.
095		262054-7	URETHANE RING 3	1	PC.
096		256A57-7	PIN 4	1	PC.
097		422B13-7	PUSHER CUSHION	1	PC.
098		265915-0	HEX. SOCKET HEAD BOLT M6X10	1	PC.
099		267426-1	FLAT WASHER 7	1	PC.
100		8146X6-4	DBN901 NAME PLATE	1	PC.
101		8146X8-0	DBN901 SERIAL NO.LABEL	1	PC.
A01		141X57-7	HANG HOOK ASSEMBLY (C-Shaped)	1	PC.
A02		265D55-8	H.S.H BOLT M5X12	3	PC.
A03		347C14-9	HOOK (BELT CLIP)	1	PC.
A04	1	4130T1-3	* NOSE ADAPTER	1	PC.
A05		783202-0	HEX. WRENCH 4	1	PC.
A08		-----	18V LI-ION BATTERY		
A09		-----	BATTERY CHARGER		
F01		1914P2-4	EXTENDED CAPACITY MAGAZINE SET	1	PC.

SERVICE CHANGES

1. Changes on Housing, Stator, Sensor Circuit

Item No.	Description	T/I# DV737 T/I# DX625 T/I# DY572 T/I# E0421 T/I# E3177				
		Type 1	Type 2	Type 3	Type 4	Type 5
2	Housing Set	1830P5-8	1831E2-3	1831K8-3	1831P2-0	
7	Leaf Spring	232842-6		232964-2		
19	Stator Complete	629C77-0			629D43-3	629D43-3
51	Sensor Circuit	620N67-2				620S90-7

Above parts are completely interchangeable as a set.

Service Note:

See T/I# E0421 and E3177 for Wiring Change

2. Changes on Nose Adapter

Item No.	Description	T/I# E1190	
		Type 1	Type 2
75	Contact Top	313502-0	313673-3
A04	Nose Adapter	4130T1-3	4133Y2-4

Above parts are completely interchangeable as a set.