




PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
001		458591-9	FRONT GRIP	1	PC.
002	3	265995-6	TAPPING SCREW 4X18	1	PC.
006	3	265995-6	TAPPING SCREW 4X18	7	PC.
007		854N75-3	DHS661 NAME PLATE	1	PC.
008		144251-6	INDICATION PLATE COMPLETE	1	PC.
009		140D10-0	MOTOR HOUSING COMPLETE	1	PC.
009	INC.	263005-3	RUBBER PIN 6	2	PC.
009	INC.	817J82-3	CAUTION LABEL	1	PC.
010		911263-2	PAN HEAD SCREW M5X40	3	PC.
011		419704-7	LOCK OFF BUTTON	1	PC.
012		651083-9	SWITCH C3XA-1PSM	1	PC.
013		231433-0	COMPRESSION SPRING 4	2	PC.
015		458594-3	SWITCH LEVER	1	PC.
016		632L80-6	SWITCH UNIT	1	PC.
019		644809-6	TERMINAL	1	PC.
020		854N80-0	DHS660 SERIAL NO. LABEL	1	PC.
021	1	629362-3	* STATOR	1	PC.
021	2	629B61-9	* STATOR	1	PC.
022		251517-8	TAPPING SCREW 4X40	2	PC.
023		620936-3	LED CIRCUIT	1	PC.
024	2	620A72-1	* CONTROLLER	1	PC.
024	3	620K98-3	* CONTROLLER	1	PC.
025		458585-4	HANDLE COVER	1	PC.
026		458586-2	BAFFLE PLATE	1	PC.
027		458593-5	COVER	1	PC.
028		519527-4	ROTOR ASS'Y	1	PC.
028	INC.		Item No. 29-31		
029	1	211012-0	BALL BEARING 606ZZ	1	PC.
030		240045-8	FAN 55	1	PC.
031		210059-1	BALL BEARING 6000DDW	1	PC.
032	2	233342-9	COMPRESSION SPRING 6	1	PC.
033		347400-6	SHAFT LOCK	1	PC.
034		911223-4	PAN HEAD SCREW M5X16	1	PC.
035		458589-6	DUCT	1	PC.
036		140D07-9	BLADE CASE COMPLETE	1	PC.
036	INC.	213821-3	O-RING 26	1	PC.
037		262511-5	RUBBER SLEEVE 6	1	PC.
038		265115-2	+ PAN HEAD SCREW M5	1	PC.

Item No	Type	Part No	Description	Qty	Unit
039	1	211012-0	BALL BEARING 606ZZ	1	PC.
040		961052-5	RETAINING RING S-12	1	PC.
041		226192-9	HELICAL GEAR 49	1	PC.
042		257173-2	RING 12	1	PC.
043		213512-6	O RING 39	1	PC.
044		135993-3	BEARING BOX ASSEMBLY	1	PC.
044	INC.		Item No. 43		
045		265034-2	+ COUNTERSUNK HEAD SCREW M5X16	2	PC.
046	2	210216-1	BALL BEARING 6001DDW	1	PC.
047		285843-3	BEARING RETAINER 19-29	1	PC.
048	2	327244-0	SPINDLE	1	PC.
049		345469-4	THICKNESS RING	1	PC.
050		231832-6	TENSION SPRING 3	1	PC.
051		458587-0	SAFETY COVER	1	PC.
052		961152-1	RETAINING RING (EXT) S-34	1	PC.
053		224411-7	INNER FLANGE 35	1	PC.
054		224409-4	OUTER FLANGE 35	1	PC.
055		266925-0	HEX.SOCKET HEX.BOLT M6X18	1	PC.
056		286036-5	CAP	1	PC.
057		347399-5	LEVER PLATE	1	PC.
058		257982-9	BOW STOP RING E-8	1	PC.
059	2	252265-2	HEX. NUT M6	1	PC.
061		266737-1	FLAT HEAD SQ. NECK BOLT M6X20	1	PC.
062		252631-3	SCREW M6	1	PC.
064		941151-9	FLAT WASHER 6	1	PC.
065		161898-1	DEPTH GUIDE COMPLETE	1	PC.
066		265939-6	FLAT HEAD SQ. NECK BOLT M6X14	1	PC.
067		347401-4	REAR GUIDE PLATE	1	PC.
068		265648-7	PAN HEAD SCREW M4X8	2	PC.
069		252103-8	HEX. LOCK NUT M5-8	1	PC.
070		345590-9	ANGULAR GUIDE	1	PC.
071		256480-0	SHOULDER PIN 6-7	1	PC.
072		318823-5	STOPPER	1	PC.
073		213977-2	O RING 7	1	PC.
074		266734-7	+ TRUSS HEAD SCREW M5	1	PC.
075		251896-4	SCREW M5X20	1	PC.
076		231007-7	COMPRESSION SPRING 6	1	PC.
077		319715-1	ANGULAR PLATE	1	PC.
079	2	265B21-3	HEX.BOLT M6X20	1	PC.

Item No	Type	Part No	Description	Qty	Unit
080		271446-9	LEVER 45	1	PC.
081		257982-9	BOW STOP RING E-8	1	PC.
082		347397-9	BASE	1	PC.
083		265085-5	+ COUNTERSUNK HEAD SCREW M4X8	2	PC.
084		912212-2	COUNTERSUNK HEAD SCREW M5X12	4	PC.
085		266436-5	H.S.SET SCREW(FLAT POINT)M5X8	3	PC.
086	2	620K37-3	* CONTROLLER B	1	PC.
087	2	652119-7	* PH SCREW M2X6	6	PC.
A01	2	783217-7	HEX. WRENCH 5	1	PC.
A02		A-85092	6-1/2" CT BLADE 24T 5/8"	1	PC.
A03		164095-8	GUIDE RULE	1	PC.
A04		199230-9	DUST NOZZLE SET	1	PC.
A04	INC.	911233-1	PAN HEAD SCREW M5X20	1	PC.
A07		197212-5	INTERLOCKING CASE	1	PC.
A07	INC.	453974-8	LATCH	4	PC.
A08		T-02571	FORM F/ INTERLOCKING CASE L	3	PC.
A09		---	BATTERY ACCESSORIES		
A10		---	BATTERY CHARGER		
A11		---	18V LI-ION BATTERIES		
A14		194385-5	CLAMP SET	1	PC.
A18		194419-4	POSITION SHEET 3000 SET	1	PC.
A24		199826-6	RATCHET CLAMP SET	1	PC.
F01		199140-0	GUIDE RAIL 1000	1	PC.
F02		194367-7	GUIDE RAIL 3000 SET	1	PC.
F03		194368-5	GUIDE RAIL 1400 SET	1	PC.
F04		199141-8	GUIDE RAIL 1500	1	PC.
F05		194416-0	SHEET 10000 SET	1	PC.
F06		194417-8	RUBBER SHEET 10000 SET	1	PC.
F07		194418-6	POSITION SHEET 1400 SET	1	PC.
F10		194910-2	POSITION SHEET 1900 SET	1	PC.
F12		194925-9	GUIDE RAIL 1900 SET	1	PC.
F15		199231-7	HANG HOOK SET	1	PC.
F16		199232-5	GUIDE RAIL ADAPTER SET	1	PC.
G49		1913K5-7	PUSH CLAMP SET	1	PC.

SERVICE CHANGES: DHS660

1. Changes on M6 Hex Nut

(T/I#D0825)

Item No.	Description	Type 1	Type 2
059	HEX. NUT M6	264096-7	252265-2
060	FLAT WASHER 6	267118-2	-----

Above parts are completely interchangeable as a set.

SERVICE CHANGES

2. Changes on M6x20 Hex Bolt

(T/I#D0825)

Item No.	Description	Type 1	Type 2
079	HEX. BOLT M6X20	266735-5	265B21-3
078	FLAT WASHER 6	941151-9	-----

Above parts are completely interchangeable as a set.

Center of Bow faces right
when it is assembled to
the following parts.

Bow stop E ring




Center of Bow faces left
when it is assembled to
the following parts.

Bow stop E ring




M6 Hex nut: 264096-7

Ring 6: 257285-1




M6 Hex nut: 264096-7

Flat washer 6: 267118-2



M6x20 Hex bolt: 266735-5

Flat washer 6: 941151-9



M6 Hex nut: 252290-3



M6 Hex nut: 252265-2



M6x20 Hex bolt: 265B21-3



3. Changes on Stator

(T/I#C5919)

(T/I#DG534)

Item No.	Description	Type 1	Type 2	Type 3
21	STATOR	629362-3		629B61-9
24	CONTROLLER	620935-5	620A72-1	620K98-3
86	CONTROLLER B	-----		620K37-3
87	PAN HEAD SCREW M2X6	-----		652119-7
D01	INSULATED CONNECTOR 5.5-SD	654510-5	-----	

Above parts are completely interchangeable as a set.

See T/I#DG534 for wiring and repair.