




## PARTS LIST

| Item No | Type | Part No    | Description                    | Qty | Unit |
|---------|------|------------|--------------------------------|-----|------|
| 001     |      | SE00001125 | TOP PANEL                      | 1   | PC.  |
| 002     |      | SE00001127 | TAPPING SCREW 3X12(ZK)         | 6   | PC.  |
| 003     |      | SE00001128 | TOP COVER                      | 1   | PC.  |
| 004     |      | SE00001129 | O RING D37.8 W2                | 1   | PC.  |
| 005     |      | SE00001130 | FLASH LIGHT LENS               | 1   | PC.  |
| 006     |      | SE00001131 | LED LENS                       | 1   | PC.  |
| 008     |      | SE00001127 | TAPPING SCREW 3X12(ZK)         | 4   | PC.  |
| 009     |      | SE00001134 | LED HOLDER+PCB F ASS'Y (MR054) | 1   | PC.  |
| 009     | INC. |            | Item No. 10                    |     |      |
| 010     |      | SE00001136 | RUBBER PAD A                   | 2   | PC.  |
| 011     |      | SE00001137 | HANDLE                         | 1   | PC.  |
| 013     |      | SE00001138 | WATERPROOF PLUG A              | 1   | PC.  |
| 014     |      | SE00001139 | TOP CABINET ASS'Y              | 1   | PC.  |
| 015     |      | SE00001140 | HEX SOCKET HEAD BOLT M4X16     | 4   | PC.  |
| 016     |      | SE00001141 | FIXER BAR                      | 1   | PC.  |
| 017     |      | SE00001216 | HEX SOCKET HEAD BOLT M4X13     | 1   | PC.  |
| 018     |      | SE00001127 | TAPPING SCREW 3X12(ZK)         | 4   | PC.  |
| 019     |      | SE00001144 | SPEAKER                        | 1   | PC.  |
| 020     |      | SE00001146 | PACKING                        | 1   | PC.  |
| 021     |      | SE00001147 | ANT WIRE                       | 2   | PC.  |
| 022     |      | SE00001148 | SCREW STB 3X12(MC)             | 4   | PC.  |
| 023     |      | SE00001149 | WATERPROOF PLUG B              | 1   | PC.  |
| 024     |      | SE00001150 | LAMP COVER ASS'Y               | 1   | PC.  |
| 025     |      | SE00001141 | FIXER BAR                      | 1   | PC.  |
| 026     |      | SE00001216 | HEX SOCKET HEAD BOLT M4X13     | 1   | PC.  |
| 027     |      | SE00001141 | FIXER BAR                      | 1   | PC.  |
| 028     |      | SE00001216 | HEX SOCKET HEAD BOLT M4X13     | 1   | PC.  |
| 029     |      | SE00001141 | FIXER BAR                      | 1   | PC.  |
| 030     |      | SE00001216 | HEX SOCKET HEAD BOLT M4X13     | 1   | PC.  |
| 031     |      | SE00001218 | HEX SOCKET HEAD BOLT 3X12      | 4   | PC.  |
| 032     |      | SE00001152 | PCB D+E LIGHT CTRL ASS'Y       | 1   | PC.  |
| 033     |      | SE00001127 | TAPPING SCREW 3X12(ZK)         | 5   | PC.  |
| 034     |      | SE00001224 | REAR BOTTOM CABINET ASS'Y      | 1   | PC.  |
| 034     | INC. |            | Item No. 35                    |     |      |
| 035     |      | SE00001158 | USB RUBBER COVER               | 1   | PC.  |
| 036     |      | SE00001159 | PCB K ASS'Y                    | 1   | PC.  |
| 037     |      | SE00001160 | TAPPING SCREW 2X6              | 2   | PC.  |
| 038     | 1    | SE00001226 | PCB H ASS'Y (USB JACK)         | 1   | PC.  |

| Item No | Type | Part No    | Description                    | Qty | Unit |
|---------|------|------------|--------------------------------|-----|------|
| 038     | 2    | SE00001331 | PCB H ASS'Y (USB JACK)         | 1   | PC.  |
| 039     |      | SE00001160 | TAPPING SCREW 2X6              | 4   | PC.  |
| 040     |      | SE00001163 | BOTTOM CABINET PACKING D1.5xL2 | 1   | PC.  |
| 041     |      | SE00001165 | LXT TERMINAL(18V) ASS'Y        | 1   | PC.  |
| 042     |      | SE00001160 | TAPPING SCREW 2X6              | 4   | PC.  |
| 043     |      | SE00001228 | PCB A ASS'Y                    | 1   | PC.  |
| 044     |      | SE00001160 | TAPPING SCREW 2X6              | 4   | PC.  |
| 045     |      | SE00001233 | PCB C ASS'Y(FCC)               | 1   | PC.  |
| 047     |      | SE00001237 | FRONT BOTTOM CABINET ASS'Y     | 1   | PC.  |
| A01     |      | SE00001178 | STRAP WITH HOOK                | 1   | PC.  |
| A02     |      | -----      | BATTERY CHARGER                | 1   | PC.  |
| A03     |      | -----      | 18V LI-ION BATTERY             | 1   | PC.  |
| A04     |      | 450128-8   | BATTERY COVER                  | 1   | PC.  |