




## PARTS LIST

| Item No | Type | Part No  | Description                   | Qty | Unit |
|---------|------|----------|-------------------------------|-----|------|
| 001     |      | 911243-8 | PAN HEAD SCREW M5X25          | 1   | PC.  |
| 002     |      | 266130-9 | TAPPING SCREW BIND PT 3X16    | 11  | PC.  |
| 003     |      | 1831E0-7 | HOUSING SET                   | 1   | SET  |
| 003     | INC. | 263005-3 | RUBBER PIN 6                  | 2   | PC.  |
| 003     | INC. | 252126-6 | HEX. LOCK NUT M4-7            | 2   | PC.  |
| 003     | INC. | 252103-8 | HEX. LOCK NUT M5-8            | 1   | PC.  |
| 004     |      | 632V61-0 | SWITCH UNIT                   | 1   | PC.  |
| 005     |      | 232889-0 | LEAF SPRING                   | 1   | PC.  |
| 006     |      | 650060-8 | SWITCH C3JR-5BM-PAND-2        | 1   | PC.  |
| 007     |      | 232884-0 | COMPRESSION SPRING 7          | 1   | PC.  |
| 008     | 2    | 1413L6-2 | TRIGGER COMPLETE              | 1   | PC.  |
| 009     |      | 654908-6 | TERMINAL                      | 1   | PC.  |
| 010     |      | 232876-9 | COMPRESSION SPRING 7          | 2   | PC.  |
| 011     |      | 652069-6 | FLAT HEAD SCREW M3X6          | 3   | PC.  |
| 012     |      | 620P18-7 | CONTROLLER                    | 1   | PC.  |
| 013     |      | 266490-9 | TAPPING SCREW PT 2X6          | 3   | PC.  |
| 014     |      | 629A28-1 | STATOR                        | 1   | PC.  |
| 015     |      | 210231-5 | BALL BEARING 625ZZ            | 1   | PC.  |
| 016     |      | 519865-4 | ROTOR ASS'Y                   | 1   | PC.  |
| 016     | INC. |          | Item No. 15                   |     |      |
| 017     |      | 210005-4 | BALL BEARING 608DDW           | 1   | PC.  |
| 018     |      | 4130V8-3 | LED HOLDER                    | 1   | PC.  |
| 019     |      | 620P87-8 | LED CIRCUIT                   | 1   | PC.  |
| 020     |      | 266007-8 | TAPPING SCREW BIND PT 3X10    | 2   | PC.  |
| 022     |      | 620P99-1 | SWITCH CIRCUIT COMPLETE       | 1   | PC.  |
| 023     |      | 327D23-0 | VALVE CAP                     | 1   | PC.  |
| 024     |      | 213007-9 | O RING 8                      | 1   | PC.  |
| 025     |      | 243138-0 | VALVE CORE                    | 1   | PC.  |
| 026     |      | 312H24-5 | TOP CAP                       | 1   | PC.  |
| 027     |      | 922232-8 | HEX. SOCKET HEAD BOLT M5X20   | 4   | PC.  |
| 028     | 1    | 213A78-2 | X-RING 23                     | 1   | PC.  |
| 028     | 2    | 213B07-1 | X-RING 23                     | 1   | PC.  |
| 029     |      | 4130T8-9 | SLIDE RING                    | 2   | PC.  |
| 030     |      | 137286-4 | DRIVER ASS'Y                  | 1   | PC.  |
| 031     |      | 8149C6-5 | DST630 NAME PLATE             | 1   | PC.  |
| 032     |      | 8149C8-1 | DST630 SERIAL NO. LABEL       | 1   | PC.  |
| 033     |      | 259092-8 | SPIRAL RETAINING RING (EXT)36 | 1   | PC.  |
| 034     |      | 422B82-8 | SEAL RING                     | 1   | PC.  |

| Item No | Type | Part No  | Description            | Qty | Unit |
|---------|------|----------|------------------------|-----|------|
| 035     |      | 141Y40-0 | CHAMBER COMPLETE       | 1   | PC.  |
| 036     | 2    | 213A95-2 | O RING 33              | 2   | PC.  |
| 037     |      | 327E19-7 | CYLINDER               | 1   | PC.  |
| 038     |      | 422B80-2 | FRONT CUSHION          | 1   | PC.  |
| 039     |      | 122G77-8 | GEAR ASSEMBLY          | 1   | PC.  |
| 040     |      | 227B71-6 | SPUR GEAR 14           | 4   | PC.  |
| 041     |      | 141Y39-5 | CARRIER COMPLETE       | 1   | PC.  |
| 042     |      | 210168-6 | BALL BEARING 6805DDW   | 1   | PC.  |
| 043     |      | 265E16-4 | TAPPING SCREW 4X18     | 2   | PC.  |
| 044     |      | 911002-0 | PAN HEAD SCREW M3X6    | 1   | PC.  |
| 045     |      | 620P94-1 | SENSOR CIRCUIT         | 1   | PC.  |
| 046     |      | 1411R3-8 | INNER HOUSING COMPLETE | 1   | PC.  |
| 047     |      | 265E16-4 | TAPPING SCREW 4X18     | 4   | PC.  |
| 048     |      | 347C87-2 | FLAT WASHER 10         | 1   | PC.  |
| 049     |      | 961006-2 | RETAINING RING S-10    | 1   | PC.  |
| 050     |      | 162D48-5 | HOLDER COMPLETE        | 1   | PC.  |
| 051     |      | 347C92-9 | LIFTER PLATE           | 1   | PC.  |
| 052     |      | 327E17-1 | LIFTER                 | 1   | PC.  |
| 053     |      | 268054-5 | PIN 4                  | 6   | PC.  |
| 054     |      | 234227-2 | COMPRESSION SPRING 3   | 1   | PC.  |
| 055     |      | 327E18-9 | LIFTER SHAFT           | 1   | PC.  |
| 056     |      | 211391-6 | BALL BEARING 6900LLU   | 1   | PC.  |
| 057     |      | 4130X3-7 | LIFTER CAP             | 1   | PC.  |
| 058     |      | 911102-6 | PAN HEAD SCREW M4X6    | 1   | PC.  |
| 059     |      | 347C90-3 | MAGAZINE STOPPER       | 1   | PC.  |
| 060     |      | 327E20-2 | GUIDE SHAFT            | 2   | PC.  |
| 061     |      | 232892-1 | COMPRESSION SPRING 4   | 2   | PC.  |
| 063     |      | 137288-0 | MAGAZINE ASS'Y         | 1   | PC.  |
| 063     | INC. | 8081T4-0 | CAUTION LABEL          | 1   | PC.  |
| 063     | INC. | 8085R2-4 | CAUTION LABEL          | 1   | PC.  |
| 063     | INC. |          | Item No. 58-61         |     |      |
| 064     |      | 4130W6-4 | LEAF SPRING            | 1   | PC.  |
| 065     |      | 347C89-8 | PUSHER                 | 1   | PC.  |
| 066     |      | 4130X1-1 | PUSHER GUIDE           | 1   | PC.  |
| 067     |      | 951069-6 | SPRING PIN 3-20        | 1   | PC.  |
| 068     |      | 4130X2-9 | LOCK LEVER             | 1   | PC.  |
| 069     |      | 232891-3 | COMPRESSION SPRING 6   | 1   | PC.  |
| 070     |      | 4130W9-8 | MAGAZINE END           | 1   | PC.  |
| 071     |      | 232893-9 | COMPRESSION SPRING 3   | 1   | PC.  |

| Item No | Type | Part No  | Description                 | Qty | Unit |
|---------|------|----------|-----------------------------|-----|------|
| 072     |      | 347C91-1 | PLATE                       | 1   | PC.  |
| 073     |      | 266130-9 | TAPPING SCREW BIND PT 3X16  | 1   | PC.  |
| 074     |      | 951063-8 | SPRING PIN 3-16             | 1   | PC.  |
| 075     |      | 162D47-7 | SUB MAGAZINE                | 1   | PC.  |
| 077     |      | 232882-4 | COMPRESSION SPRING 9        | 1   | PC.  |
| 078     |      | 140W22-7 | SWITCH COMPLETE             | 1   | PC.  |
| 079     |      | 232883-2 | LEAF SPRING                 | 1   | PC.  |
| 080     |      | 141Y69-6 | ADJUSTER COMPLETE           | 1   | PC.  |
| 081     |      | 213021-5 | O RING 5                    | 1   | PC.  |
| 082     |      | 961017-7 | STOP RING E-3               | 1   | PC.  |
| 083     |      | 347C93-7 | CONTACT ARM                 | 1   | PC.  |
| 084     |      | 422B94-1 | NOSE ADAPTER                | 1   | PC.  |
| 085     |      | 313614-9 | DRIVER GUIDE                | 1   | PC.  |
| 086     |      | 922148-7 | HEX. SOCKET HEAD BOLT M4X25 | 4   | PC.  |
| 087     |      | 313577-9 | DRIVER GUIDE COVER          | 1   | PC.  |
| A01     |      | 251314-2 | + TRUSS HEAD SCREW M4X12    | 1   | PC.  |
| A02     |      | 346449-3 | HOOK                        | 1   | PC.  |
| A03     |      | 422B94-1 | NOSE ADAPTER                | 2   | PC.  |
| A04     |      | -----    | 18V LI-ION BATTERY          |     |      |
| A05     |      | -----    | BATTERY CHARGER             |     |      |

## SERVICE CHANGES: DST630

### 1. Changes on X RING 23

(T/I#E4141)

| Item No. | Description | Type 1   | Type 2   |
|----------|-------------|----------|----------|
| 28       | X RING 23   | 213A78-2 | 213B07-1 |

X-rings will be changed to cold-resistant specification as follows

