




PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
001		911243-8	PAN HEAD SCREW M5X25	1	PC.
002		266130-9	TAPPING SCREW BIND PT 3X16	11	PC.
003		1831E0-7	HOUSING SET	1	SET
003	INC.	263005-3	RUBBER PIN 6	2	PC.
003	INC.	252126-6	HEX. LOCK NUT M4-7	2	PC.
003	INC.	252103-8	HEX. LOCK NUT M5-8	1	PC.
004		632V61-0	SWITCH UNIT	1	PC.
005		232889-0	LEAF SPRING	1	PC.
006		650060-8	SWITCH C3JR-5BM-PAND-2	1	PC.
007		232884-0	COMPRESSION SPRING 7	1	PC.
008		4130V7-5	TRIGGER	1	PC.
009		654908-6	TERMINAL	1	PC.
010		232876-9	COMPRESSION SPRING 7	2	PC.
011		652069-6	FLAT HEAD SCREW M3X6	3	PC.
012		620P18-7	CONTROLLER	1	PC.
013		266490-9	TAPPING SCREW PT 2X6	3	PC.
014		629A28-1	STATOR	1	PC.
015		210231-5	BALL BEARING 625ZZ	1	PC.
016		519865-4	ROTOR ASS'Y	1	PC.
016	INC.		Item No. 15		
017		210005-4	BALL BEARING 608DDW	1	PC.
018		4130V8-3	LED HOLDER	1	PC.
019		620P87-8	LED CIRCUIT	1	PC.
020		266007-8	TAPPING SCREW BIND PT 3X10	2	PC.
022		620P99-1	SWITCH CIRCUIT COMPLETE	1	PC.
023		327D23-0	VALVE CAP	1	PC.
024		213007-9	O RING 8	1	PC.
025		243138-0	VALVE CORE	1	PC.
026		312H24-5	TOP CAP	1	PC.
027		922232-8	HEX. SOCKET HEAD BOLT M5X20	4	PC.
028		213A78-2	X-RING 23	1	PC.
029		4130T8-9	SLIDE RING	2	PC.
030		137286-4	DRIVER ASS'Y	1	PC.
031		8149C6-5	DST630 NAME PLATE	1	PC.
032		8149C8-1	DST630 SERIAL NO. LABEL	1	PC.
033		259092-8	SPIRAL RETAINING RING (EXT)36	1	PC.
034		422B82-8	SEAL RING	1	PC.
035		141Y40-0	CHAMBER COMPLETE	1	PC.
036		213479-8	O RING 33	2	PC.
037		327E19-7	CYLINDER	1	PC.
038		422B80-2	FRONT CUSHION	1	PC.
039		122G77-8	GEAR ASSEMBLY	1	PC.

Item No	Type	Part No	Description	Qty	Unit
040		227B71-6	SPUR GEAR 14	4	PC.
041		141Y39-5	CARRIER COMPLETE	1	PC.
042		210168-6	BALL BEARING 6805DDW	1	PC.
043		265E16-4	TAPPING SCREW 4X18	2	PC.
044		911002-0	PAN HEAD SCREW M3X6	1	PC.
045		620P94-1	SENSOR CIRCUIT	1	PC.
046		1411R3-8	INNER HOUSING COMPLETE	1	PC.
047		265E16-4	TAPPING SCREW 4X18	4	PC.
048		347C87-2	FLAT WASHER 10	1	PC.
049		961006-2	RETAINING RING S-10	1	PC.
050		162D48-5	HOLDER COMPLETE	1	PC.
051		347C92-9	LIFTER PLATE	1	PC.
052		327E17-1	LIFTER	1	PC.
053		268054-5	PIN 4	6	PC.
054		234227-2	COMPRESSION SPRING 3	1	PC.
055		327E18-9	LIFTER SHAFT	1	PC.
056		211391-6	BALL BEARING 6900LLU	1	PC.
057		4130X3-7	LIFTER CAP	1	PC.
058		911102-6	PAN HEAD SCREW M4X6	1	PC.
059		347C90-3	MAGAZINE STOPPER	1	PC.
060		327E20-2	GUIDE SHAFT	2	PC.
061		232892-1	COMPRESSION SPRING 4	2	PC.
063		137288-0	MAGAZINE ASS'Y	1	PC.
063	INC.	8081T4-0	CAUTION LABEL	1	PC.
063	INC.	8085R2-4	CAUTION LABEL	1	PC.
063	INC.		Item No. 58-61		
064		4130W6-4	LEAF SPRING	1	PC.
065		347C89-8	PUSHER	1	PC.
066		4130X1-1	PUSHER GUIDE	1	PC.
067		951069-6	SPRING PIN 3-20	1	PC.
068		4130X2-9	LOCK LEVER	1	PC.
069		232891-3	COMPRESSION SPRING 6	1	PC.
070		4130W9-8	MAGAZINE END	1	PC.
071		232893-9	COMPRESSION SPRING 3	1	PC.
072		347C91-1	PLATE	1	PC.
073		266130-9	TAPPING SCREW BIND PT 3X16	1	PC.
074		951063-8	SPRING PIN 3-16	1	PC.
075		162D47-7	SUB MAGAZINE	1	PC.
077		232882-4	COMPRESSION SPRING 9	1	PC.
078		140W22-7	SWITCH COMPLETE	1	PC.
079		232883-2	LEAF SPRING	1	PC.
080		141Y69-6	ADJUSTER COMPLETE	1	PC.
081		213021-5	O RING 5	1	PC.

Item No	Type	Part No	Description	Qty	Unit
082		961017-7	STOP RING E-3	1	PC.
083		347C93-7	CONTACT ARM	1	PC.
084		422B94-1	NOSE ADAPTER	1	PC.
085		313614-9	DRIVER GUIDE	1	PC.
086		922148-7	HEX. SOCKET HEAD BOLT M4X25	4	PC.
087		313577-9	DRIVER GUIDE COVER	1	PC.
A01		251314-2	+ TRUSS HEAD SCREW M4X12	1	PC.
A02		346449-3	HOOK	1	PC.
A03		422B94-1	NOSE ADAPTER	2	PC.
A04		-----	18V LI-ION BATTERY		
A05		-----	BATTERY CHARGER		