





## PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
001		1410X3-4	NUT COMPLETE	1	PC.
002		137204-2	SPROCKET COVER ASS'Y	1	PC.
002	INC.		Item No. 1,3		
003		422833-7	GROMMET	1	PC.
004	1	162A04-7	TANK CAP COMPLETE	1	PC.
004	1	INC. 213A11-4	O-RING 25	1	PC.
004	2	162E50-4	TANK CAP COMPLETE	1	PC.
004	2	INC. 213B01-3	O-RING 25	1	PC.
005		266492-5	TAPPING SCREW 3X8	1	PC.
006		413M03-7	COVER	1	PC.
007		347A69-2	TENSION SLIDE	1	PC.
008		232787-8	COMPRESSION SPRING 4	1	PC.
009		413M02-9	STOPPER	1	PC.
010		233211-4	COMPRESSION SPRING 2	1	PC.
011		961013-5	STOP RING E-7	1	PC.
012		227947-5	SPROCKET 7 - BULK	1	PC.
013		1830V8-4	HOUSING SET	1	SET
013	INC.	263005-3	RUBBER PIN 6	4	PC.
014		210274-7	BALL BEARING 6000DDW	1	PC.
015		327A89-2	SPINDLE	1	PC.
016		227B67-7	SPIRAL BEVEL GEAR 71	1	PC.
017		211166-3	BALL BEARING 698DDW	1	PC.
018		226884-0	WORM GEAR	1	PC.
019		961011-9	STOP RING E-4	1	PC.
020		422B78-9	OIL TUBE 3-67	1	PC.
021		413L02-3	* NIPPLE - Removed	1	PC.
022	1	232774-7	* COMPRESSION SPRING 6	1	PC.
023		141N25-0	OIL PUMP COMPLETE	1	PC.
024	1	422969-2	* OIL TUBE 3-25	1	PC.
024	2	422D18-9	* OIL TUBE 3-25	1	PC.
025		266427-6	TAPPING SCREW 4X12	1	PC.
027		266326-2	TAPPING SCREW 4X18	7	PC.
028		4130P7-3	HOUSING R COVER	1	PC.
029		266326-2	TAPPING SCREW 4X18	4	PC.
030		213A05-9	O-RING16	1	PC.
031		619875-2	ROTOR	1	PC.
032		629B92-8	STATOR	1	PC.
033		620P39-9	CONTROLLER	1	PC.

Item No	Type	Part No	Description	Qty	Unit
034		652069-6	FLAT HEAD SCREW M3X6	3	PC.
035		266490-9	TAPPING SCREW PT 2X6	3	PC.
036		213616-4	O RING 48	2	PC.
037		1830X0-4	PIPE HOLDER SET	1	SET
038		266326-2	TAPPING SCREW 4X18	5	PC.
039		231113-8	COMPRESSION SPRING 12	1	PC.
040		4130P6-5	LOCK OFF BUTTON B	1	PC.
041		327D94-7	PIPE A	1	PC.
042		4130R9-3	PIPE SLEEVE 32	1	PC.
043		687G57-6	RETAINER	1	PC.
044		638B00-8	LEAD UNIT A	1	PC.
045		4130R3-5	LOCK RING	1	PC.
046		4130R4-3	LOCK SCREW	1	PC.
046	INC.	931202-6	HEX. NUT M5	1	PC.
047		922243-3	HEX. SOCKET HEAD BOLT M5X25	1	PC.
048		327D96-3	PIPE C	1	PC.
049		638B02-4	LEAD UNIT C	1	PC.
050		4130R9-3	PIPE SLEEVE 32	1	PC.
051		687G57-6	RETAINER	1	PC.
052		4130R3-5	LOCK RING	1	PC.
053		638B01-6	LEAD UNIT B	1	PC.
054		4130R4-3	LOCK SCREW	1	PC.
054	INC.	931202-6	HEX. NUT M5	1	PC.
055		922243-3	HEX. SOCKET HEAD BOLT M5X25	1	PC.
056		1410G6-9	PIPE B COMPLETE US	1	PC.
056	INC.	8016N4-7	CAUTION LABEL	1	PC.
057		1830V7-6	GRIP HOUSING SET	1	SET
057	INC.	263005-3	RUBBER PIN 6	2	PC.
058	2	231469-9	COMPRESSION SPRING 4	1	PC.
059		650033-1	SWITCH C3XA-3PSPM-1	1	PC.
060		4130Y0-0	LOCK OFF BUTTON A	1	PC.
061	2	231469-9	COMPRESSION SPRING 4	1	PC.
062		4130R8-5	SWITCH LEVER	1	PC.
063		643874-2	TERMINAL	1	PC.
064		266326-2	TAPPING SCREW 4X18	7	PC.
066		327810-3	BATTERY GUARD	1	PC.
067		8147J6-2	DUA200 SERIAL NO.LABEL	1	PC.
068		8147J4-6	DUA200 NAME PLATE	1	PC.
069		8085Y3-1	INDICATION LABEL	1	SET

Item No	Type	Part No	Description	Qty	Unit
A01		122D94-0	BAND ASSEMBLY	1	PC.
A02		1914S3-3	GUIDE BAR 8 SET	1	PC.
A03		199897-3	OIL VESSEL SET	1	PC.
A04		413G28-5	GUIDE BAR CASE 210	1	PC.
A05		1914S1-7	SAW CHAIN 8 SET	1	PC.
A10		196675-2	18V LI-ION BATTERY BL1850B	1	PC.
A11		DC18RC	RAPID CHARGER DC18RC	1	PC.
C01		8205N6-8	CARTON FOR DUA200Z	1	PC.

# SERVICE CHANGES: DUA200

## 1. Changes on Compression spring 6, Oil Tube & Nipple (T/I#E3716)

Item No.	Description	Type 1	Type 2
22	COMPRESSION SPRING 6	232774-7	-----
	SPRING 6	-----	232989-6
24	OIL TUBE 3-25	422969-2	422D18-9
21	NIPPLE	413L02-3	-----

Above parts are completely interchangeable as a set.



