



PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
001		911118-1	PAN HEAD SCREW M4X12 WR	1	PC.
002		4134A4-8	FRONT HAND GUARD RETAINER	1	PC.
003		265620-9	FLANGE TAPPING SCREW 4X18	1	PC.
004		162E50-4	TANK CAP COMPLETE	1	PC.
004	INC.	213B01-3	O-RING 25	1	PC.
005		4134A7-2	SIDE HANDLE	1	PC.
006		422467-6	CAP	1	PC.
007		266326-2	BINDING HEAD TAPPING SCREW 4X18	8	PC.
008		266420-0	BINDING HEAD TAPPING SCREW 5X20	2	PC.
009		1832D6-4	HOUSING SET	1	SET
009	INC.		Item No. 6, 43		
009	INC.	263005-3	RUBBER PIN 6	2	PC.
009	INC.	8095H6-9	CAUTION LABEL	1	PC.
010		347E26-4	HOOK SUPPORT	1	PC.
011		327F97-3	HOOK	1	PC.
012		620S35-5	SWITCH CIRCUIT	1	PC.
013		651365-9	SWITCH C3JW-6BM-P	1	PC.
014		1413D6-6	LOCK OFF LEVER COMPLETE	1	PC.
015		232867-0	TORSION SPRING 10	1	PC.
016		459282-5	SWITCH LEVER	1	PC.
017		643874-2	TERMINAL	1	PC.
018		8153W0-4	DUC258 SERIAL NO. LABEL	1	PC.
019		620S58-3	CONTROLLER	1	PC.
020		632W82-8	SWITCH UNIT	1	PC.
021		266427-6	BINDING HEAD TAPPING SCREW 4X12	1	PC.
022		422D25-2	OIL TUBE 3-106	1	PC.
023		1412G6-1	OIL PUMP COMPLETE	1	PC.
024		422D02-4	OIL TUBE 3-56	1	PC.
025		231975-4	SPRING	1	PC.
026		452666-6	NIPPLE	1	PC.
027		911118-1	PAN HEAD SCREW M4X12 WR	3	PC.
028		961011-9	STOP RING (EXT) E-4	1	PC.
029		226884-0	WORM GEAR	1	PC.
030		4134A6-4	MOTOR COVER	1	PC.
031		619925-3	ROTOR	1	PC.
032	1	265C89-5	FLAT HEAD SCREW M3X10	2	PC.
032	2	265F08-9	FLAT HEAD SCREW M3X10	2	PC.
033		620S36-3	CONTROLLER B	1	PC.

Item No	Type	Part No	Description	Qty	Unit
034		520211-6	STATOR ASS'Y	1	PC.
034	INC.		Item No. 35, 36		
035		210258-5	BALL BEARING 6900DDW	1	PC.
036		962112-6	RETAINING RING (INT) ROUND R-22	1	PC.
037		961006-2	RETAINING RING (EXT) S-10	1	PC.
039		4134A3-0	FRONT HAND GUARD	1	PC.
040		8153V9-9	DUC258 NAME PLATE	1	PC.
041		232453-7	COMPRESSION SPRING 3	1	PC.
042		313672-5	HAND GUARD GUIDE	1	PC.
043		1832D6-4	HOUSING SET	1	SET
043	INC.	263005-3	RUBBER PIN 6	2	PC.
043	INC.	8095H6-9	CAUTION LABEL	1	PC.
043	INC.		Item No. 6, 9		
044		347373-3	CHAIN CATCHER	1	PC.
045		1412B7-4	LINK PLATE COMPLETE	1	PC.
046		232452-9	COMPRESSION SPRING 7	1	PC.
047		266326-2	BINDING HEAD TAPPING SCREW 4X18	4	PC.
048		4134A9-8	HOUSING R COVER A	1	PC.
049	2	347F39-1	BRAKE BAND	1	PC.
050	2	162E85-5	BRAKE DRUM COMPLETE	1	PC.
051		213060-5	O-RING 10	1	PC.
052		4133T6-1	HOUSING R COVER B	1	PC.
053		266326-2	BINDING HEAD TAPPING SCREW 4X18	1	PC.
054		227C50-0	SPROCKET 6 - BULK	1	PC.
055		961013-5	STOP RING (EXT) E-7	1	PC.
056		227620-7	DRIVE GEAR	1	PC.
057		227634-6	STRAIGHT BEVEL GEAR 14	1	PC.
058		347569-6	TENSION SLIDE	1	PC.
059		327900-2	ADJUST SCREW	1	PC.
060		227496-2	STRAIGHT BEVEL GEAR 14	1	PC.
061		347E47-6	GUIDE PLATE L	1	PC.
062		266905-6	HEXALOBULAR SOCKET HEAD BOLT M5X12	1	PC.
063		266326-2	BINDING HEAD TAPPING SCREW 4X18	1	PC.
064		266427-6	BINDING HEAD TAPPING SCREW 4X12	1	PC.
065		347E46-8	GUIDE PLATE R	1	PC.
066		422310-9	CHIP GUIDE	1	PC.
067		162494-8	FLANGE NUT COMPLETE	1	PC.
068		4134A2-2	NUT COVER	1	PC.
069		137398-3	SPROCKET COVER ASS'Y	1	PC.

Item No	Type	Part No	Description	Qty	Unit
069	INC.		Item No. 64-68		
A01		191G14-3	10" SPROCKET GUIDE BAR 3/8" 43G	1	PC.
A02		D-70954	FILE HOLDER SET 4.5MM(11/64)	1	PC.
A03		458501-6	GUIDE BAR CASE	1	PC.
A04		191H00-0	3/8" CHAIN 43G 10" (90PX40)	1	PC.
A05		782042-3	BOX WRENCH 13	1	PC.
A06		-----	18V LI-ION BATTERY		
A07		-----	BATTERY CHARGER		
F16		227C49-5	SPROCKET 7- BULK	1	PC.