




PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
001		266326-2	TAPPING SCREW 4X18	6	PC.
002		811W45-9	SP001G NAME PLATE	1	PC.
003		183U02-8	HANDLE SET	1	SET
003	INC.	263005-3	RUBBER PIN 6	1	PC.
003	INC.	813D02-9	CAUTION LABEL	1	PC.
004		811W53-0	SP001G SERIAL NO. LABEL	1	PC.
005		632P65-6	TERMINAL UNIT	1	PC.
006	1	141D05-6	TERMINAL HOUSING COMPLETE	1	PC.
006	1	INC. 263005-3	RUBBER PIN 6	1	PC.
007		266326-2	TAPPING SCREW 4X18	2	PC.
008		266326-2	TAPPING SCREW 4X18	2	PC.
009		651083-9	SWITCH C3XA-1PSPM	1	PC.
010		234078-3	COMPRESSION SPRING 4	1	PC.
011		457748-9	SWITCH LEVER	1	PC.
012		419629-5	LOCK OFF BUTTON	1	PC.
013		233089-5	COMPRESSION SPRING 12	1	PC.
014		457749-7	LOCK PLATE	1	PC.
015		233267-7	COMPRESSION SPRING 7	1	PC.
016		324709-3	LOCK PIN 8	1	PC.
017		911253-5	PAN HEAD SCREW M5X30	2	PC.
019		140F99-0	CAP COMPLETE	1	PC.
019	INC.	213A05-9	O-RING16	1	PC.
019	INC.	818H07-8	CAP LABEL	1	PC.
020		266326-2	TAPPING SCREW 4X18	5	PC.
021		413844-3	REAR COVER	1	PC.
022		620F56-9	DIAL CIRCUIT	1	PC.
023	1	620F55-1	* CONTROLLER	1	PC.
023	2	620R72-3	* CONTROLLER	1	PC.
024		413840-1	MOTOR HOUSING	1	PC.
025		911253-5	PAN HEAD SCREW M5X30	4	PC.
026	1	629A81-7	* STATOR	1	PC.
026	2	629C14-4	* STATOR	1	PC.
027		413845-1	BAFFLE PLATE	1	PC.
028		266326-2	TAPPING SCREW 4X18	2	PC.
029		210022-4	BALL BEARING 626DDW	1	PC.
030		519698-7	ROTOR ASSY	1	PC.
030	INC.		Item No. 29,31		
031		211131-2	BALL BEARING 6001DDW	1	PC.

Item No	Type	Part No	Description	Qty	Unit
032		345742-2	SHAFT LOCK	1	PC.
033		286039-9	CAP	1	PC.
034		233084-5	COMPRESSION SPRING 6	1	PC.
035		286040-4	CAP	1	PC.
036		141D07-2	GEAR HOUSING COMPLETE	1	PC.
036	INC.	263002-9	RUBBER PIN 4	1	PC.
037		324708-5	STOPPER PIN 8	1	PC.
038	1	324716-6	PIN 8	1	PC.
038	2	327B66-0	PIN 8	1	PC.
039		266213-5	H.S.SET SCREW(FLAT POINT)M5X12	1	PC.
040		211021-9	BALL BEARING 607LLB	1	PC.
041		961052-5	RETAINING RING S-12	1	PC.
042		221548-1	HELICAL GEAR 41	1	PC.
043		257010-0	RING 12	1	PC.
044		213512-6	O RING 39	1	PC.
045		318088-9	BEARING BOX	1	PC.
046		211129-9	BALL BEARING 6201DDW	1	PC.
047		324707-7	SPINDLE	1	PC.
048		285689-7	BEARING RETAINER 55	1	PC.
049		911221-8	PAN HEAD SCREW M5X16	2	PC.
050		266034-5	TAPPING SCREW CT 4X16	2	PC.
051		419630-0	LOCK LEVER	1	PC.
052		231665-9	TORSION SPRING 7	1	PC.
053		253821-1	FLAT WASHER 3	1	PC.
054		266007-8	TAPPING SCREW BIND PT 3X10	1	PC.
055		413847-7	DEPTH GUIDE	1	PC.
056		265762-9	THUMB SCREW M5X30	1	PC.
057		941101-4	FLAT WASHER 5	1	PC.
058		419623-7	STOPPER BLOCK	1	PC.
059		231372-4	COMPRESSION SPRING 5	1	PC.
060		345744-8	NUT PLATE	1	PC.
061		233479-2	COMPRESSION SPRING 11	1	PC.
062		419624-5	SPRING HOLDER	1	PC.
063		253010-8	FLAT WASHER 6	1	PC.
064	2	266351-3	TAPPING SCREW 4X35	1	PC.
065		141D06-4	BLADE CASE COMPLETE	1	PC.
065	INC.		Item No. 66-70		
066		286041-2	CAP 14	2	PC.
067		345747-2	SPACER PLATE	2	PC.

Item No	Type	Part No	Description	Qty	Unit
068		233025-1	COMPRESSION SPRING 2	2	PC.
069		347392-9	PLATE	2	PC.
070		259008-3	PUSH NUT 4	2	PC.
071		213460-9	O RING 35	1	PC.
072		413846-9	DUST NOZZLE	1	PC.
073		144867-7	LEVER 20 COMPLETE	1	PC.
073	INC.	263002-9	RUBBER PIN 4	1	PC.
074		266034-5	TAPPING SCREW CT 4X16	1	PC.
075		419632-6	POSITION PLATE	1	PC.
076		213021-5	O RING 5	1	PC.
077		324710-8	PIN 8	1	PC.
078		224593-5	INNER FLANGE 35	1	PC.
079		224409-4	OUTER FLANGE 35	1	PC.
080		266403-0	HEX. SOCKET HEAD BOLT M6	1	PC.
081		312B61-3	BLADE CASE COVER	1	PC.
082		266034-5	TAPPING SCREW CT 4X16	5	PC.
083		8025F3-0	XGT LOGO LABEL	1	PC.
084		458092-7	SLIDE LEVER	1	PC.
085		253932-2	WAVE WASHER 10	1	PC.
086		345977-5	PLATE	1	PC.
087		265775-0	THUMB SCREW M4X3	2	PC.
088		419627-9	HOLDER	2	PC.
089		265701-9	THUMB SCREW M6X14	2	PC.
090	2	231240-1	COMPRESSION SPRING 7	2	PC.
091	1	265776-8	* THUMB SCREW M6X26	1	PC.
091	2	265E79-0	* THUMB SCREW M6X24	1	PC.
092		253111-2	* FLAT WASHER 6 (Removed)	1	PC.
093		419596-4	REAR ANGULAR GUIDE	1	PC.
094		312B64-7	BASE	1	PC.
095		266326-2	TAPPING SCREW 4X18	2	PC.
096		266225-8	H.S.SET SCREW(FLAT POINT)M6X8	2	PC.
097		266326-2	TAPPING SCREW 4X18	2	PC.
098		345748-0	LOCK WASHER	1	PC.
099		912112-6	COUNTERSUNK HEAD SCREW M4X10	1	PC.
100		413A11-6	FRONT ANGULAR GUIDE	1	PC.
101		252157-5	SQUARE NUT M6	1	PC.
102		266225-8	H.S.SET SCREW(FLAT POINT)M6X8	1	PC.
103		324731-0	STOPPER PIN	1	PC.
104		457963-5	DIAL 22	1	PC.

Item No	Type	Part No	Description	Qty	Unit
105		961017-7	STOP RING E-3	1	PC.
106		253111-2	* FLAT WASHER 6 (Removed)	1	PC.
107	1	265776-8	* THUMB SCREW M6X26	1	PC.
107	2	265E79-0	* THUMB SCREW M6X24	1	PC.
108		232674-1	LEAF SPRING	2	PC.
109	2	620N49-4	* CONTROLLER B	2	PC.
110	2	652119-7	* PH SCREW M2X6	6	PC.
A01		B-57342	TCT BLADE165X20X56TWOOD/MDF DB	1	PC.
A02	2	783217-7	HEX. WRENCH 5	1	PC.
A04		8040F3-6	SP001GZ02 MODEL NO. LABEL	1	PC.
A06	2	197213-3	INTERLOCKING CASE XL	1	PC.
A06	2	INC. 453974-8	LATCH	4	PC.
A08		412393-7	BATTERY COVER F/ XGT LI-ION	1	PC.
A09		BL4050F	40V MAX LI-ION BATTERY BL4050F	1	PC.
A09		BL4025	40V MAX LI-ION BATTERY BL4025	1	PC.
A09		BL4040	40V MAX LI-ION BATTERY BL4040	1	PC.
A10		DC40RA	FAST CHARGER DC40RA	1	PC.
A11		194368-5	GUIDE RAIL 1400MM	1	PC.
F03		194367-7	GUIDE RAIL 3000 SET	1	PC.
F04		194368-5	GUIDE RAIL 1400 SET	1	PC.
F06		194416-0	SHEET 10000 SET	1	PC.
F07		194417-8	RUBBER SHEET 10000 SET	1	PC.
F08		194418-6	POSITION SHEET 1400 SET	1	PC.
F14		195546-0	FRONT CUFF 24 SET	1	PC.
F15		196664-7	BEVEL GUIDE SET	1	PC.
F16		199140-0	GUIDE RAIL 1000 SET	1	PC.
F17		199141-8	GUIDE RAIL 1500 SET	1	PC.
F28		1913K7-3	PARALLEL GUIDE SET (MM)	1	PC.

SERVICE CHANGES: SP001G

1. Changes on Controller, Stator, Controller B (T/I#DW726)

Item No.	Description	Type 1	Type 2
23	CONTROLLER	620F55-1	620R72-3
26	STATOR	629A81-7	629C14-4
109	CONTROLLER B	-----	620N49-4
110	PAN HEAD SCREW M2X6	-----	652119-7


Above parts are completely interchangeable as a set.

2. Changes on Thumb Screw, Flat Washer 6 (T/I#E1448)

Item No.	Description	Type 1	Type 2
92, 106	FLAT WASHER 6	253111-2	-----
91, 107	THUMB SCREW M6X26	265776-8	265E79-0

Above parts are completely interchangeable as a set.

Thumb screw M6x26 (265776-8)



Flat washer 6 (253111-2)