




PARTS LIST

Item No	Type	Part No	Description	Qty	Unit
001		413W79-4	FRONT HANDLE	1	PC.
002		266326-2	TAPPING SCREW 4X18	4	PC.
003		122A77-2	TANK CAP ASSEMBLY	1	PC.
003	INC.	213A30-0	O-RING 29.5	1	PC.
004		422467-6	CAP	1	PC.
005		266326-2	TAPPING SCREW 4X18	9	PC.
006		1830U8-7	HOUSING SET	1	SET
006	INC.	8074U0-0	CAUTION LABEL	1	PC.
007		266427-6	TAPPING SCREW 4X12	1	PC.
008		422B10-3	OIL TUBE 3-134	1	PC.
009		140L95-4	OIL PUMP COMPLETE	1	PC.
010		961011-9	STOP RING E-4	1	PC.
011		226884-0	WORM GEAR	1	PC.
012		422B09-8	OIL TUBE 3-114	1	PC.
013		231975-4	SPRING	1	PC.
014		452666-6	NIPPLE	1	PC.
015		266326-2	TAPPING SCREW 4X18	3	PC.
016		413W73-6	MOTOR HOUSING	1	PC.
017		652119-7	PAN HEAD SCREW M2X6	3	PC.
018		632V15-7	SENSOR UNIT	1	PC.
019		620N62-2	CONTROLLER	1	PC.
020		652069-6	FLAT HEAD SCREW M3X6	3	PC.
021		629C60-7	STATOR	1	PC.
022		266326-2	TAPPING SCREW 4X18	2	PC.
023		413W74-4	BAFFLE PLATE	1	PC.
024		210016-9	BALL BEARING 698ZZ	1	PC.
025		519840-0	ROTOR ASSEMBLY	1	PC.
025	INC.		Item No. 24,26		
026		210059-1	BALL BEARING 6000DDW	1	PC.
027		620N64-8	SWITCH CIRCUIT COMPLETE	1	PC.
028		141V01-2	LOCK OFF LEVER COMPLETE	1	PC.
029		232850-7	TORSION SPRING 10	1	PC.
030		413C93-0	SWITCH LEVER	1	PC.
031		650048-8	SWITCH C3JR-4B-PAND6-1	1	PC.
032		266326-2	TAPPING SCREW 4X18	2	PC.
033		1830H3-6	TERMINAL BOX SET	1	SET
033	INC.	263005-3	RUBBER PIN 6	2	PC.
034		266326-2	TAPPING SCREW 4X18	3	PC.

Item No	Type	Part No	Description	Qty	Unit
035		632V23-8	TERMINAL UNIT	1	PC.
037		652031-1	PAN HEAD SCREW M3X6	2	PC.
038		266326-2	TAPPING SCREW 4X18	1	PC.
039		413W72-8	MICRO SWITCH GUARD	1	PC.
040		650057-7	SWITCH D2SW-P01L30-3M-C2(S)	1	PC.
042		911118-1	PAN HEAD SCREW M4X12	2	PC.
043		413W82-5	FRONT HAND GUARD RETAINER	1	PC.
044		413W68-9	FRONT HAND GUARD	1	PC.
045		213594-8	O RING 7	1	PC.
046		313398-9	HAND GUARD GUIDE	1	PC.
047		234210-9	COMPRESSION SPRING 3	1	PC.
048		266326-2	TAPPING SCREW 4X18	2	PC.
049		347925-0	SPIKE BUMPER	1	PC.
050		347924-2	CHAIN CATCHER	1	PC.
051		266326-2	TAPPING SCREW 4X18	1	PC.
052		347C01-8	GUIDE PLATE	1	PC.
053		347C02-6	GUIDE PLATE R	1	PC.
054		266427-6	TAPPING SCREW 4X12	2	PC.
055		327D00-2	ADJUST PIN	1	PC.
056		266427-6	TAPPING SCREW 4X12	1	PC.
057		413W88-3	COVER	1	PC.
058		327C99-1	ADJUST SCREW	1	PC.
059		227496-2	STRAIGHT BEVEL GEAR 14	1	PC.
060		227B20-3	STRAIGHT BEVEL GEAR 14	1	PC.
061		137157-5	SPROCKET COVER ASS'Y	1	PC.
061	INC.		Item No. 53-60,62-67		
062		162D07-9	NUT COMPLETE	1	PC.
063		413W85-9	NUT COVER	1	PC.
064		213011-8	O RING 7	1	PC.
065		413W87-5	DIAL 40	1	PC.
066		232788-6	RING SPRING 7	1	PC.
067		413W89-1	CAP	1	PC.
068		141E60-4	LINK PLATE COMPLETE	1	PC.
069		347922-6	BRAKE BAND COMPLETE	1	PC.
070		232452-9	COMPRESSION SPRING 7	1	PC.
071		137076-5	BRAKE COVER ASSEMBLY	1	PC.
072		266326-2	TAPPING SCREW 4X18	3	PC.
073		162979-4	BRAKE DRUM	1	PC.
074		213060-5	O RING 10	1	PC.

Item No	Type	Part No	Description	Qty	Unit
075	1	227905-1	SPROCKET 7	1	PC.
075	2	191V91-5	SPROCKET 7 SET	1	PC.
076		961013-5	STOP RING E-7	1	PC.
077		8144L6-8	UC023G NAME PLATE	1	PC.
078		8144L7-6	UC023G SERIAL NO.LABEL	1	PC.
A01		191T88-2	GUIDE BAR 16 SET	1	PC.
A02		413G21-9	GUIDE BAR CASE 460	1	PC.
A03		199897-3	OIL VESSEL SET	1	PC.
A04		191T92-1	SAW CHAIN 16 SET	1	PC.
A05		782023-7	WRENCH 13-16	1	PC.
A06		-----	40V MAX LI-ION BATTERY		
A07		-----	BATTERY CHARGER		
C01		8204N8-8	CARTON FOR UC023G	1	PC.